









































### Composizione posto esterno ALBA video o audio chiamata su fila singola

NUMERO CHIAMATE		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	
MODULO A/V	 <b>CV2124AB/CA2124AB</b>	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
MOD. NEUTRO/CIVICO	 <b>AB00/AB50</b>															1	1	1	1						2	2	2	2	1	1	1	1				
MOD. TASTI	 <b>CT2138AB</b>			1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6	7	7	7	7	8	8	8	8	8
TASTO /NEUTRO	 <b>AB21</b>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	
	 <b>AB20</b>	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		
SCATOLE INCASSO	 <b>SC1</b>	1	1																																	
	 <b>SC2</b>			1	1	1	1					2	2	2	2																					
	 <b>SC3</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3
TETTUCCI PARAPIOGGIA	 <b>AB91</b>	1	1																																	
	 <b>AB92</b>			1	1	1	1																													
	 <b>AB93</b>						1	1	1	1																										
	 <b>AB94</b>											1	1	1	1																					
	 <b>AB96</b>															1	1	1	1	1	1	1	1	1												
TELAI	 <b>AB71</b>	1	1																																	
	 <b>AB72</b>			1	1	1	1					2	2	2	2																					
	 <b>AB73</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3
CORNICI	 <b>AB61</b>	1	1																																	
	 <b>AB62</b>			1	1	1	1					2	2	2	2																					
	 <b>AB63</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3
CAVO	 <b>EC733</b>											1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	

scegliere SC\_ per montaggio da incasso, AB9\_ per montaggio di superficie

### Composizione posto esterno ALBA video o audio chiamata su fila doppia

NUMERO CHIAMATE		2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68	
MODULO A/V	 <b>CV2124AB/CA2124AB</b>	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
MOD. NEUTRO/CIVICO	 <b>AB00/AB50</b>															1	1	1	1						2	2	2	2	1	1	1	1				
MOD. TASTI	 <b>CT2138AB</b>			1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6	7	7	7	7	8	8	8	8	
TASTO /NEUTRO	 <b>AB21</b>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	
	 <b>AB20</b>	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		3	2	1		
SCATOLE INCASSO	 <b>SC1</b>	1	1																																	
	 <b>SC2</b>			1	1	1	1					2	2	2	2																					
	 <b>SC3</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	
TETTUCCI PARAPIOGGIA	 <b>AB91</b>	1	1																																	
	 <b>AB92</b>			1	1	1	1																													
	 <b>AB93</b>						1	1	1	1																										
	 <b>AB94</b>											1	1	1	1																					
	 <b>AB96</b>															1	1	1	1	1	1	1	1	1												
TELAJ	 <b>AB71</b>	1	1																																	
	 <b>AB72</b>			1	1	1	1					2	2	2	2																					
	 <b>AB73</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	
CORNICI	 <b>AB61</b>	1	1																																	
	 <b>AB62</b>			1	1	1	1					2	2	2	2																					
	 <b>AB63</b>						1	1	1	1						2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	
CAVO	 <b>EC733</b>											1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2		

scegliere SC\_ per montaggio da incasso, AB9\_ per montaggio di superficie